


# PCU-X00 WirelessHART Repeater – Installer Reference



## Safety Information

The PCU-X00 Repeater has been certified for operation in hazardous locations under the following parameters and conditions:

- Class 1, Division 1, Groups C, and D;
- Intrinsically safe Ex ia;
- Ambient temperature range -40°C to +60°C, Temperature Code T4;
- Pollution degree 4
- Water submersion to a depth of 1m (3.28 ft.)
- Enclosure is Type 4X and IP67

Specific Conditions of Use:

1. A passive antenna may be supplied by the manufacturer or provided by the customer. Permitted antennas must have <10 000mm<sup>2</sup> plastic surface when connected directly to the enclosure. Antennas connected through an extension cable are not subject to the plastic surface area restriction.
2. When a non-metallic antenna is connected directly to the enclosure, it is possible that under certain extreme circumstances, the non-metallic antenna may generate an ignition-capable level of electrostatic charge. Therefore, when a non-metallic antenna is connected to the enclosure without the use of an extension cable, the equipment shall be installed in a location where the external conditions are conducive to the build-up of electrostatic charge on such surfaces. In addition, the equipment shall only be cleaned with a damp cloth.
3. The HART maintenance port in the PCU must not be used in the hazardous area. When used in the non-hazardous area, a battery-powered HART Field Communicator with intrinsic safety approvals shall be used. Examples are the Emerson 375 or 475 HART Field Communicator, and the AMS Trex Device Communicator.


**WARNING: Substitution of components not expressly specified by Syscor will void intrinsic safety certification.**

**WARNING: Do not open in an explosive gas atmosphere.**


**WARNING: Do not power on without first connecting an antenna.**

Syscor's battery-powered WirelessHART Repeater may be used to improve or extend any WirelessHART network, even networks provided by other vendors. The 136.8Wh battery pack provides 10+ years lifespan. The Repeater may not be used with attached Syscor sensor probes.


## Package 1 – Standard Configuration Kit




## Package 1-1 – Mounting bracket




**Package 1-2** – Install the Repeater to a strut or pole




**Package 1-3** – Antenna Install




**Package 1-4** – Power the Repeater




**Package 2** – Radio Frequency Splitter Configuration Kit




**Package 2-1** – Mounting bracket




**Package 2-2** – RHCP antenna mounting bracket




The RHCP Antenna bracket has 5 holes for varying C-Clamp position or U-Bolt orientation as required by the installation site





**Package 2-3** – Install the Repeater to a strut or pole




**Package 2-4** – Install the antennas and RF splitter






### Package 2-5 – Power the Repeater



### Package 2-6 – Aboveground Storage Tank Installation Example




## WirelessHART Networking

The PCU-X00 commonly comes with client-specific gateway join settings already loaded. The following box shows the default network ID and join key:

Network ID:  
**1234**

Join Key:  
Part 1: **44555354**  
Part 2: **4E455457**  
Part 3: **4F524B53**  
Part 4: **524F434B**

## Change the Network ID and Join Key with a HART Field Communicator




HART Field Communicator loaded with the Syscor Device Descriptor.  
(Contact Syscor for a copy of the Device Descriptor)

Connect to the Maintenance Port with J-clips

## Using the Field Communicator


The following is the menu tree for the HART Field Communicator loaded with the PCU Device Descriptor.




## Syscor WiHART Config Tool

Syscor offers a software tool for adjusting settings remotely once a PCU-X00 has joined the WirelessHART Gateway.

**Step 1** - Run `syscor-wihart-config-tool.exe` (no installation needed)



**Step 2** - Connect to the gateway using the gateway's IP address and HART-IP port.



**Step 3** - Select the PCU to be configured from the device list.





**Syscor Controls & Automation Inc.**

201-60 Bastion Square  
Victoria, BC V8W 1J2, Canada  
Toll Free (US & Canada): +1-833-361-1681  
Tel: +1-250-361-1681  
Fax: +1-250-361-1682  
[www.syscor.com](http://www.syscor.com)

© 2023, Syscor Controls & Automation Inc., all rights reserved. The contents of this publication, or any part thereof, may not be reproduced or transmitted in any form by any means, electronic or mechanical, including photocopying, recording, storage in an information retrieval system, or otherwise, without the prior, written approval of Syscor.